

FOAM WATER SPRINKLER



TECHNICAL DATA

MODEL	F
MOUNTING	Pendent
MAXIMUM WORKING PRESSURE	12 Bar (175 PSI)
OPERATING PRESSURE	2.1 Bar (30 PSI) minimum 4.2 Bar (60 PSI) maximum
END CONNECTION	1/2" BSPT (1/2" NPT Optional)
MATERIAL	Brass and Bronze
K-FACTOR	K-42 standard Other K-factor can be provided as optional
FINISH	Natural Brass finish
WEIGHT (Approx)	0.750 Kg
ORDERING INFORMATION	Specify Model, end connection

APPLICATION

The Foam-Water Sprinklers are used in the deluge foam system to protect the risk where foam is required to be applied from overhead sprinklers and is to be followed with plain water in a standard sprinkler pattern.

Foam Water Sprinklers protect the loading and unloading area in the event of a spill fire with low expansion foam systems. These are useful in other wide applications including Air Craft Hangars.

SPECIFICATION

Foam Water Sprinklers are open and air aspirating type. The pattern of coverage is similar to the conventional sprinkler head. The Foam Water Sprinkler has standard orifice with K-factor of 42.

Foam Water Sprinklers are designed to operate at a minimum of 2.1 bar pressure and maximum of 4.2 bar. The Foam Water Sprinkler with K-42 will deliver about 61 LPM at 2.1 bar pressure. The standard coverage per Foam Water Sprinkler is 9.3sq.m. (100 sq.ft.)

SYSTEM DESIGN

The following are a few guidelines for minimum requirement of foam system design.

- Foam solution discharge rate : Area of hazard X application rate.



- Minimum foam solution application rate required as per NFPA is 6.5LPM/sq.m. for the area of hazard to be protected.

MAINTENANCE

The water foam sprinkler must be handled with due care. For best results, the storage as well as any further shipment be made in original packing only.

Water foam sprinkler which is visibly damaged should not be installed.

Use Teflon tape or soft thread sealant on male thread of the sprinkler. The sprinkler must be hand tightened into the fitting. Excessive tightening torque may result into serious damage to sprinkler arms and the deflector which may affect spray pattern of the nozzle and its performance.

It is recommended that water foam spray system be inspected regularly by authorised technical personnel

The nozzle must be checked for atmospheric effects, external and internal obstruction, blockage if any. The nozzle should be cleaned or replaced if required. The system must be operated with optimum water flow at least twice in a year or as per the provisions of NFPA/TAC or as per authority having jurisdiction.